



Note: Amp1,2,3, outputs go to analog multiplexor

see sheet 2

Current Sensor (4 Ch- 5V)

For 0.01 ohm Shunts

R Bruce McCreary

Rev 2.0

2/19/2008

Page # or name